
70-2105

RED WIRE NOTE



The 70-2105 comes with both a red wire in the [harness](#) and also a loose red wire. **The red wire in the harness will only be used in the 2007-11 CHEVROLET AVEO and the 2007-09 PONTIAC G3.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12-volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12-volt accessory lead.
