



70-5518

***INSTALLATION
INSTRUCTIONS***

Ford Tremor
Amplifier Integration
[Harness](#)



Wires NOT used on the
16 pin harness:

White, White with Black, Gray, &
Gray with Black

Just tape up these wires so they do
not get in the way.

The front speakers get their signal
from the White (left) and Gray (right)
RCA's and the subwoofer gets its
signal from the Green and Purple
RCA's. the subwoofer RCA's are
combined together to achieve a
mono input signal even with radios
that do not have a dedicated sub-
woofer output. The Blue with White
stripe wire is to be connected to the
radios amp turn-on wire.