



70-6502

Chrysler wire harness 2002-2010

***Note:** For the following vehicles there is not an accessory wire present in the factory harness. A wire must be run to the fuse box for accessory power, or use the XSVI-6502-NAV wiring harness.*

APPLICATIONS

CHRYSLER

300	2005-2007
Aspen	2007
PT Cruiser	2006-2010

APPLICATIONS

DODGE

Caliber	2007-2008
Charger	2006-2007
Dakota	2005-2007
Durango	2004-2007
Magnum	2005-2007
Ram	2006-2010

JEEP

Commander	2006-2007
Compass	2007-2008
Grand Cherokee	2005-2007
Patriot	2007-2008

MITSUBISHI

Raider	2006-2007
--------	-----------
