



70-6522

***INSTALLATION
INSTRUCTIONS***

Chrysler/Dodge/Jeep
2007-Up

Wiring Harness

2007 AND UP

CHRYSLER/DODGE/JEEP VEHICLES



Due to the fact that a switched 12-volt accessory lead does NOT exist in the factory harness, an accessory source must be located.

- 1.** Using the separate red wire provided with the fuse tap, locate an accessory power source in the vehicle's fuse box.
- 2.** Connect this red wire to the aftermarket head unit switched accessory lead.
- 3.** Use Metra's standard wiring instructions for the remainder of the installation.