



70-8112

***INSTALLATION
INSTRUCTIONS***

1992-1999

Toyota

AMP Integration Harness



PIN	COLOR	FUNCTION
1	Blue / White	AMP Turn On
2	Orange	Illumination
3	Red	Accessory
4	Yellow	Constant 12V
5	Brown / White	Mute
6	White	Lt Front AMP input (+)
7	Gray	Rt Front AMP input (+)
8	Blue	Power Antenna
9	Not Used	N/A
10	Brown	Telephone Mute
11	Black	Ground
12	Black / White	Signal Ground
13	Brown / Yellow	Beep
14	Green	Lt Rear AMP input (+)
15	Purple	Rt Rear AMP input (+)