

## 70-8114

## INSTALLATION INSTRUCTIONS Toyota/Lexus/Scion ASWC-1 harness

LEXUS ES 330	2005-2006	RX 350 RX400H	2007-2010 2006-2008	Highlander* Land Cruiser	2004-up 2003-2007
ES 350 2007-2009 GS 300/350/430/430h/460 2006-2008			2012-2013 2006-2013	Land Cruiser (non-NAV) 2008-2013 Matrix* (standard audio)	
GS 350/450h/460 GX Series HS 250h IS 250/250C/350/3	2009 2003-2009 2010 50C/ISE	xA xB xD	2006 2006-2012 2008-2013	Prius RAV4 Seguoia*	2009-2013 2004-2009 2004-2011 2003-up
LS 460/600h LX 470 LX 570 RX Series	2006-2010 2007-2009 2003-2009 2008-2009 2004-2009	<b>TOYOTA</b> 4Runner* Avalon Camry Corolla <i>(all trims)</i>	2003-up 2005-2012 2005-2011 2009-2012	Sienna Solara Tacoma Tundra Venza	2004-up 2004-2008 2005-2012 2003-2013 2009-2012
RX 330	2004-2009	FJ Cruiser*	2009-2012 2007-up	Yaris (sedan)	2009-2012

\*Note, these models, the OE steering wheel harness must be 20-pin. *Models needing a 28-pin harness must use the AX-TOY28SWC. This applies to the 2013-up models only.* 

When installing an aftermarket radio, the 70-8114 will allow the user to retain their factory installed steering wheel controls without having to splice into the factory wiring (ASWC-1 required and sold separately). In addition, we include RCA's to allow the user to retain their factory installed 3.5mm AUX IN jack (aftermarket radio must have a audio AUX IN).

## **INSTALLATION:**

- 1. Connect the **Red** wire to 12-volt accessory power.
- 2. Connect the Black wire to chassis ground (by itself).
- 3. Connect the 3.5mm jack to the steering wheel control input, in the aftermarket radio.
- 4. Connect the White RCA jack to the left audio AUX IN of the aftermarket radio (if equipped).
- 5. Connect the **Red** RCA to the right audio AUX IN of the aftermarket radio (if equipped).

## NOTE:

- 1. Audio devices connected through the 3.5mm jack will be controlled from the audio device, not the aftermarket radio.
- 2. Please refer to the ASWC-1 programming instructions for programming of the ASWC-1.