



70-8116

INSTALLATION

INSTRUCTIONS

Toyota

Power and Amplifier

Bypass Harness

THESE **HARNESSES** ARE DESIGNED FOR THE 2000-04 TOYOTA AVALON, 2000-06 TOYOTA CAMRY, 2003-05 TOYOTA CELICA, 2001-06 TOYOTA HIGHLANDER, 2000-06 TOYOTA LANDCRUISER AND THE 2000-03 TOYOTA SOLARA WITH THE AMPLIFIED JBL SYSTEM. A POWER HARNESS IS SUPPLIED TO ALLOW THE USER TO WIRE THE AFTERMARKET RADIO UP WITHOUT THE NEED TO PURCHASE A SEPARATE WIRE HARNESS.



FACTORY AMP LOCATIONS:

2000-04 Toyota Avalon: Under passenger seat

2000-06 Toyota Camry:

Behind glove box near passenger side

2003-05 Toyota Celica:

Behind glove box near passenger side

2001-06 Toyota Highlander: Behind passenger side quarter panel

2000-06 Toyota Landcruiser: Under passenger seat

2000-03 Toyota Solara:

Behind glove box near passenger side

Wire Colors for Bypass Harness:

Green/White Subwoofer (+) Coil-1

White/Red Subwoofer (-) Coil-1

Brown/Yellow Subwoofer (+) Coil-2

Brown/Blue Subwoofer (-) Coil-2

- The rest of the wires are standard Metra / EIA color code that can be found on the back of this package.

NOTE:

The Toyota Camry, Celica, Highlander and Solara do not use the subwoofer wires, so the wires should be taped off. The 2003-04 Avalon will use only the subwoofer coil 1 wires, and the Landcruiser will use both sets of subwoofer wires.