## 70-8215 INSTRUCTIONS

## **Applications**

## **2005-2009 TOYOTA AVALON**

(Non amplified systems only)

70-8215 is designed to keep the factory radio in the vehicle so the climate control functions are still displayed through the factory display panel.

- 1. Follow the dash disassembly instructions as listed in the 99-8215 installation kit's instructions.
- 2. Find a suitable location to retain the factory radio and, from the dash opening, route the 10-way and 20-way plugs to that location and plug into the back of the factory radio. (Metra recommends securing and covering the radio behind a panel in the trunk)
- 3. Make all necessary wiring connections to the aftermarket radio harness from the 10-way and 6-way connectors as shown on the back of the harness package or in the kit instructions. Connect them to the mating connections in the dash originally in the back of the factory radio.
- 4. Plug the 20-way plug originally in the back of the factory radio into the 20-way cap from the <u>harness</u> (in heat shrink).
- 5. Complete installation as listed in the installation kit instructions.

