



70-9003 INSTALLATION **INSTRUCTIONS**

2002-Up BMW / VOLKSWAGEN

2002-2006 MINI

2007-2008 MINI CONVERTIBLE

For all vehicles except MINI:

Using the long red wire included with [the harness](#), connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

MINI COOPER ONLY

