



70-9401

INSTALLATION INSTRUCTIONS

1994-2006

**Mercedes, Smart,
Land Rover and Sprinter
multi-use [harness](#)**



The additional red wire included in this package is for Smart models 2011-up. Insert the red wire into the location next to the yellow wire as shown as pin 10 in the diagram below. For reference, pins 1-8 are speaker wires and pin 16 is ground.

| | | | | |
|---|---|--|----|----|
| | | | | |
| | | | | |
| 1 | 5 | | 9 | 13 |
| 2 | 6 | | 10 | 14 |
| 3 | 7 | | 11 | 15 |
| 4 | 8 | | 12 | 16 |