

Chevy **Silverado /** GMC **Sierra** (extended cab, rear door) **2007–2014**


KIT FEATURES

• Adapts an aftermarket 6" - 63/4" speaker to the factory rear speaker locations

KIT COMPONENTS

• A) (2) Speaker adapter plates • B) (4) #8 x 3/4" Phillips screws







TOOLS REQUIRED

• Panel removal tool • Phillips screwdriver • 10mm socket wrench • Drill (optional)

APPLICATIONS

CHEVROLET *		GMC *	
Silverado 2500/3500	2014	Sierra 2500/3500	2014
Silverado	2008-2013	Sierra	2008-2013
Silverado (new body)	2007	Sierra (new body)	2007

^{*} For extended cab, rear door applications only

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

DISASSEMBLY

- Remove both window plastic trims from the door.
- 2. Remove (2) plastic covers, one inside the door handle and one inside the door lever.
- **3.** Remove (3) 10mm bolts exposed.
- 4. Remove the power window switch.
- 5. Unclip the door panel starting from the bottom, then lift up on the panel to remove it (you do not have to remove it completely to gain access to the speaker, just move it to the side).
- **6.** Remove (1) 10mm bolt from the speaker, then unplug and remove the speaker.

KIT ASSEMBLY

- **1.** Attach the speaker to the speaker adapter plate using the hardware provided with the speaker.
- **2.** Clip the speaker assembly into place and secure with the factory hardware.
- **3.** (2) screws have been provided for additional support.