



## WIK346 Installation Kit

Thank you for purchasing the WIK346 Wiring Kit. We've designed it to make the 346 and similar pump installation as clean and easy as possible.

### In the Kit:

- 30 AMP Bosch relay
- Harness w/ 20 AMP fuse
- 1 – 18-22ga. T-Tap
- 1 – 18-22ga. Male Spade Terminal
- 1 – 10-12ga. Ring Terminal
- 1 – 14-16ga. Ring Terminal
- 1 – 14-16ga. Butt connector
- 1 – 2.5" 3/16 heat shrink tubing

### Wiring for Ford Modular applications:

- Orange wire #30 to backside of alternator at 12 volt post
- Black #85 to ground
- Blue wire #87 to fused blue wire to water pump
- Green #86 to "key on" source (found inside fuse panel)
- Or to fuel injector trigger wire at the injector

### Wiring for all other applications:

- Orange wire #30 to positive battery post or 12 volt source
- Black #85 to ground
- Blue wire #87 to fused blue wire to water pump
- Green #86 to "key on" source

