

INSTALLING THE MISHIMOTO SILICONE HOSE KIT

1. Install the Mishimoto upper radiator hose. Be sure to clamp both ends. Do not overtighten.
2. Attach the coolant reservoir hose to the port just under the filler cap.
3. Install the lower radiator hose the same way as the upper hose.



FILLING YOUR COOLANT SYSTEM

1. Make sure the car is on level ground.
2. Take the radiator cap off and fill the radiator with coolant.
3. Leave the cap off and start the car to allow the water pump to run.
4. When the fluid level drops, add more coolant to make sure that no air enters the system.
5. Let the car fully warm up and turn on the heater inside the car to its hottest temperature and highest fan speed to pull the coolant completely through the system.