

Make/Model/Year	System Adapter	Cap Adapter
ACURA		
CL 1997 –		
Integra 1990-1993	MVA102	MVA202
1994-1999	MVA101	MVA201
Legend 1991-1996	MVA102	MVA202
MDX 2001 –	MVA102	MVA202
TL 1995 –	MVA102	MVA202
ALFA ROMEO		
164 w/ threaded filler neck	MVA105	MVA205
AUDI		
w/ male thread on expansion tank 1975-1993	MVA104	MVA204
A4 1996 –	MVA108	MVA208
A6 1998 –	MVA108	MVA208
A8 1997 –	MVA108	MVA208
TT 2000 –	MVA108	MVA208
BMW		
– 1987 w/ threaded filler neck	MVA112	MVA207
3 Series 1998 –	MVA113	MVA213
5 Series 1997-2003	MVA113	MVA213
7 Series 1998 –	MVA113	MVA213
BUICK		
LeSabre 1990 –	MVA100	MVA200
Park Avenue 1991 –	MVA100	MVA200
Roadmaster 1994-1996	MVA103	MVA203
Skylark 1992-1998	MVA103	MVA203
CADILLAC		
Catera 1997-2001	MVA107	MVA207
CTS 2003 –	MVA103	MVA203
Escalade 1999 –	MVA103	MVA203
Fleetwood 1994-1996	MVA103	MVA203
Seville 1998 –	MVA103	MVA203
CHEVROLET		
Beretta 1992-1996	MVA103	MVA203
Camaro 1999-2002	MVA103	MVA203
Caprice 1994-1996	MVA103	MVA203
Cavalier 1995 –	MVA103	MVA203
Corsica 1992-1996	MVA103	MVA203
Corvette 1999 –	MVA103	MVA203
Impala 1994 –	MVA103	MVA203
Lumina 1990-2001	MVA100	MVA100
Malibu 1997 –	MVA103	MVA203
Metro 1998-1998	MVA102	MVA202
1999-2001	MVA103	MVA203
Nova 1985-1998	MVA101	MVA201
Prizm 1998-1998	MVA102	MVA202
1999-2002	MVA103	MVA203
Silverado 1999 –	MVA103	MVA203
Spectrum 1985-1988	MVA101	MVA201
Sprint 1985-1988	MVA101	MVA201
Tahoe 1999 –	MVA103	MVA203
Tracker 1998	MVA102	MVA202
1999 –	MVA103	MVA203
Venture 1997 –	MVA100	MVA200
CHRYSLER		
300M 1999-2004	MVA100	MVA200
Crossfire 2004 –	MVA109	MVA209
Laser 1991-1998	MVA101	MVA201
Sebring 1995 –	MVA100	MVA200
DAEWOO		
All 1999-2001	MVA107	MVA207
DODGE		
Caravan 1989 –	MVA100	MVA200
Coit 1984-1992	MVA101	MVA201
1993-1994	MVA102	MVA202
Dakota 1989 –	MVA100	MVA102
Stealth 1991-1996	MVA101	MVA201
Stratus 1995 –	MVA100	MVA200
EAGLE		
Summit 1993-1995	MVA102	MVA202
Talon 1991-1998	MVA101	MVA201
FORD		
Contour 1995-2000	MVA107	MVA207
Crown Victoria 1993-2003	MVA103	MVA203
E Series Vans 1995 – w/ male thread	MVA103	MVA203
Escape 2001 –	MVA110	MVA210
Escort 1991 –	MVA101	MVA201
Excursion 2000 –	MVA103	MVA203
Expedition 1997 –	MVA103	MVA203
Explorer 1995-2001	MVA101	MVA201
2002 –	MVA103	MVA203
F Series Trucks 1995 –	MVA103	MVA203
Five Hundred 2005 –	MVA103	MVA203
Festiva 1988-1993	MVA101	MVA201
Fiesta 1995 –	MVA107	MVA207
Focus 1998 –	MVA107	MVA207
Fusion 2006 –	MVA107	MVA207
Probe 1989-1997	MVA101	MVA201
Ranger 1987 –	MVA101	MVA201
Taurus 1996 –	MVA103	MVA203
Tempo 1992-1994	MVA101	MVA201
Thunderbird 1989-1992	MVA101	MVA201
1993-1997 w/ V6	MVA101	MVA201
1993-1997 w/ V8	MVA103	MVA203
2002 –	MVA103	MVA203
Windstar 1995 –	MVA101	MVA201
GEO		
Metro 1989-1994	MVA101	MVA201
1995-1998	MVA102	MVA202

Make/Model/Year	System Adapter	Cap Adapter
Prizm 1998-1998	MVA101	MVA201
1998 –	MVA102	MVA202
1993-1997	MVA102	MVA202
Tracker 1989-1993	MVA101	MVA201
1994-1998	MVA102	MVA202
GMC		
Envoy 1998 –	MVA103	MVA203
Sierra 1999 –	MVA103	MVA203
Yukon 1999 –	MVA103	MVA203
HONDA		
Accord 1990-1993	MVA101	MVA201
1994 –	MVA102	MVA202
Civic 1988-1991	MVA101	MVA201
1991 –	MVA102	MVA202
Motorcycles 1991-2004	MVA101	MVA201
Odyssey 1995 –	MVA102	MVA202
Passport 1994 –	MVA101	MVA201
Pilot 2003 –	MVA102	MVA202
Prelude 1990-1998	MVA101	MVA201
HUMMER		
H2 2003 –	MVA103	MVA203
HYUNDAI		
All 1987 –	MVA101	MVA201
INFINITI		
All 1992 –	MVA101	MVA201
INTERNATIONAL		
466 engine w/ male thread on filler neck	MVA103	MVA203
1994-1998		
ISUZU		
All 1992-1997	MVA101	MVA201
1998 –	MVA102	MVA202
JAGUAR		
All 1990-1994 w/ male thread on filler neck	MVA107	MVA207
S-Type 2000 –	MVA103	MVA203
XJ8 1998 –	MVA110	MVA210
XK8 1997 –	MVA110	MVA210
X-Type 2002 –	MVA107	MVA207
JEEP		
All 1987-1990 w/ male thread	MVA105	MVA205
KIA		
Sedona 2003 –	MVA101	MVA201
LAND ROVER		
Discovery 1989-2004	MVA107	MVA207
Discovery LR3 2005 –	MVA103	MVA203
Freelander 2002	MVA105	MVA205
2003 –	MVA103	MVA203
Range Rover 1988-1994	MVA107	MVA207
1995 –	MVA113	MVA213
LEXUS		
ES 250 1990-1991	MVA102	MVA202
ES 300 1992-1993	MVA102	MVA202
1994-1999	MVA101	MVA201
GS 300 1993-1999	MVA102	MVA202
GS 400 1998-1999	MVA102	MVA202
LS 400 1990-1999	MVA101	MVA201
LX 450 1996-1999	MVA101	MVA201
LX 470 1996-1999	MVA101	MVA201
RX 330 2004 –	MVA101	MVA201
LINCOLN		
Mark VIII 1993-1998	MVA103	MVA203
Navigator 1997 –	MVA103	MVA203
Towncar 1993 –	MVA103	MVA203
MAZDA		
3 2004 –	MVA114	MVA214
All 1985-1999 not 1995 Protégé w/ 1.5L	MVA101	MVA201
MPV 1990 –	MVA101	MVA201
Protégé 1995 – 1.5 L	MVA102	MVA202
Tribute 2001 –	MVA110	MVA210
MERCEDES		
w/ threaded filler neck on expansion tank	MVA109	MVA209
(except M-Class)		
E-Class 1996 –	MVA109	MVA209
M-Class 1998 –	MVA103	MVA203
MERCURY		
Cougar 1989-1992	MVA101	MVA201
1993-1997 w/ V6	MVA101	MVA201
1993-1997 w/ V8	MVA103	MVA203
Grand Marquis 1993-2003	MVA103	MVA203
Milan 2006 –	MVA103	MVA203
Mountaineer 2002 –	MVA103	MVA203
Mystique 1995-2000	MVA107	MVA207
Sable 1996 –	MVA103	MVA203
Topaz 1992-1994	MVA101	MVA201
Tracer 1991-1999	MVA101	MVA201
Villager 1993 –	MVA101	MVA201
MERKUR		
Scorpio 1987-1989	MVA112	MVA207
MINI		
Cooper S 2002 –	MVA105	MVA205
MINISUBISHI		
300GT 1991-1998	MVA101	MVA201
Diamante 1992-1995	MVA101	MVA201
1996 –	MVA102	MVA202
Galant 1985-1993	MVA101	MVA201
1994 –	MVA102	MVA202
Mirage 1985-1992	MVA101	MVA201
1993 –	MVA102	MVA202

Make/Model/Year	System Adapter	Cap Adapter
Montero 1989-1998	MVA101	MVA201
Montero Sport 1997 –	MVA102	MVA202
Starion 1989-1993	MVA101	MVA201
NISSAN		
All 1987 –	MVA101	MVA201
OLDSMOBILE		
Achieva 1992-1998	MVA103	MVA203
Alero 1999 –	MVA103	MVA203
Aurora 1995 –	MVA103	MVA203
Cutlass 1997-1998	MVA103	MVA203
Intrigue 1999 –	MVA103	MVA203
Silhouette 1990 –	MVA100	MVA200
PEUGEOT		
206 1999 –	MVA105	MVA205
307 2004 –	MVA105	MVA205
406 1999 –	MVA105	MVA205
407 2004 –	MVA105	MVA205
807 2004 –	MVA105	MVA205
PONTIAC		
Bonneville 1990 –	MVA100	MVA200
Firebird 1999-2002	MVA103	MVA203
Grand Am 1992 –	MVA103	MVA203
Grand Prix –2003	MVA100	MVA200
2004 –	MVA103	MVA203
GTO 2004 –	MVA103	MVA203
Le Mans 1988-1993	MVA107	MVA207
Sunfire 1995 –	MVA103	MVA203
PORSCHE		
911 1999 –	MVA107	MVA207
Boxter 1997 –	MVA107	MVA207
RENAULT		
All 1985-1987	MVA105	MVA205
Avantime 2002 –	MVA105	MVA205
S-Espace 2002 –	MVA105	MVA205
SAAB		
9-2 2004 –	MVA110	MVA210
9-3 1999 –	MVA110	MVA210
9-5 1999 –	MVA110	MVA210
9-7 2004 –	MVA110	MVA210
900 1978-1993	MVA105	MVA205
1994-1998	MVA107	MVA207
9000 1986-1998	MVA105	MVA205
SATURN		
All 1990 –	MVA103	MVA203
L-Series 2000 –	MVA107	MVA207
STERLING		
All 1987-1991	MVA105	MVA205
SUBARU		
All 1984 – w/ small filler neck	MVA101	MVA201
SUZUKI		
1983-1995 w/ 16 mm deep neck	MVA101	MVA201
1989-1999 w/ 9 mm deep neck	MVA102	MVA202
XL-7 2001 –	MVA102	MVA202
TOYOTA		
4Runner 1969 –	MVA102	MVA202
1986-1995	MVA101	MVA201
Avalon 1995 –	MVA101	MVA201
Camry 1983-1989	MVA101	MVA201
1990-1991 except V6 w/ auto. trans.	MVA101	MVA201
1990-1991 V6 w/ auto. trans.	MVA102	MVA202
1992 –	MVA102	MVA202
1994-1999 4 cylinder	MVA101	MVA201
Celica 1982-1989	MVA101	MVA201
1990-1998	MVA102	MVA202
2000 –	MVA111	MVA211
Corolla 1983-1992	MVA101	MVA201
1993 –	MVA102	MVA202
Cressida 1985-1992	MVA101	MVA201
Echo 2000 –	MVA102	MVA202
Land Cruiser 1987 –	MVA101	MVA201
MR2 Spyder 2000 –	MVA111	MVA211
Paseo 1992-1997	MVA102	MVA202
Pickup 1983-1992	MVA101	MVA201
Previa 1989-1997	MVA101	MVA201
RAV4 1996 –	MVA102	MVA202
Sienna 1998-1999	MVA101	MVA201
Solara 1998 –	MVA101	MVA201
Starlet 1983-1984	MVA101	MVA201
Supra 1986-1992 not turbo	MVA101	MVA201
1990-1992 turbo	MVA102	MVA202
T100 1995-1998	MVA101	MVA201
Tacoma 1995 –	MVA101	MVA201
Tercel 1983-1990	MVA101	MVA201
1991-1999	MVA102	MVA202
VOLKSWAGEN		
1975-1993 w/ male thrd on exp. tank	MVA104	MVA204
1990-1998 w/ female thrd on filler neck of expansion tank (except 1998 Passat & new Beetle)	MVA106	MVA206
Beetle 1998 –	MVA108	MVA208
Eurovan 1990-2003	MVA106	MVA206
Golf 1983-1992	MVA104	MVA204
1993-1998	MVA106	MVA206
1999 –	MVA108	MVA208
Jetta 1999 –	MVA108	MVA208
Passat 1998 –	MVA108	MVA208
VOLVO		
Passenger vehicles w/threaded neck	MVA105	MVA205