



Jeep® JK Stainless Steel Hood Latches

Contents:

- Latch Assembly (2)
- Catch Assembly (2)



1. Remove the rubber bumpers from the existing hood latches (Figure 1a). Remove the original hood catches and hood latches as shown in Figures 1b and 1c.



Figure 1a



Figure 1b



Figure 1c

2. Install original rubber bumpers onto new Stainless Hood Catches (Figure 2a).
Notice - Failure to reinstall pad could result in paint abrasion.
Install new Hood Latch and Hood Catch onto both sides of the vehicle (Figures 2b and 2c).



Figure 2a



Figure 2b



Figure 2c

3. Tighten all hardware. Close hood and latch Stainless Hood Catches.

