



**WINDAGE TRAY, SMALL BLOCK CHEVROLET**  
**P/N 23020**

**INSTALLATION INSTRUCTIONS**

1. Requires the use of main cap studs, (available from ARP).
2. Secure the studs using washers and nuts. (We recommend the use of thread sealer such as Loctite for the nuts that sandwich the tray.)
3. When using this tray with the oil pump mounted directly to the main cap, no trimming is required.