



INSTALLATION INSTRUCTIONS
-12AN REMOTE ADAPTER KIT BIG BLOCK CHEVY

P/N 63513

PARTS LIST

- | | |
|---|--|
| (4) 3/8-16 X 7/8" STAINLESS SHCS | (4) GASKETS, BBC |
| (4) 3/8-16 X 1 1/4" STAINLESS SHCS | (2) -12AN REMOTE W/P ADAPTERS BBC |

INSTALLATION

This remote -12AN Adapter Kit is made for our customer utilizing a remote water pump application. The adapters are designed to fit in the stock water pump port location on the engine. Included in this kit are (2) sets of fasteners and (1) extra gasket set. One set of fasteners is 1/4" longer for those using a front engine motor plate.

1. Disconnect and remove the terminal from the negative battery terminal post.
2. Drain the fluid from the cooling system. Coat both sides of the supplied gaskets with a high quality gasket sealer to prevent leaks.
3. Remove the existing water pump.
4. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.
5. Coat both sides of the supplied gaskets with a high quality gasket sealer to prevent leaks.

NOTE: Lubricate the screw threads with oil prior to installation.

6. Torque the fasteners to 11 ft-lbs and final torque to 20 ft-lbs.
7. Plumb the Remote Water Pump to the radiator and engine block with -12AN fittings (not included).
8. Refill the coolant system and service the coolant system per manufacturers service manual.
9. Re-connect the negative battery terminal to its post.

Thank you for purchasing Moroso Performance Products.