



INSTALLATION INSTRUCTIONS
-12AN REMOTE ADAPTER KIT SMALL BLOCK FORD
(FITS IN PLACE OF STANDARD ROTATION WATER PUMPS)

P/N 63515

PARTS LIST

- | | |
|--|-------------------------------------|
| (2) 5/16-18 X 1" Stainless SHCS | (1) Gasket, SBF |
| (4) 5/16-18 X 3" Stainless SHCS | (1) -12AN Remote W/P Adapter |
| (3) 5/16-18 X 7/8" Stainless BHCS | |

INSTALLATION

This remote -12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapter is designed to fit in the stock water pump port location on the engine.

- 1. Disconnect and remove the terminal from the negative battery terminal post.**
- 2. Drain the fluid from the cooling system.**
- 3. Remove the existing water pump.**
- 4. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.**

NOTE: Lubricate the screw threads with oil prior to installation.

- 5. Coat both sides of the supplied gasket with a high quality gasket sealer to prevent leaks.**
- 6. Install the new fasteners and torque to 11 ft-lbs and final torque to 15 ft-lbs.**
- 7. Plumb the Remote Water Pump to the radiator and engine block with -12AN fittings (not included).**
- 8. Refill the coolant system and service the coolant system per manufacturers service manual.**
- 9. Re-connect the negative battery terminal to its post.**

Thank you for purchasing Moroso Performance Products.