

INSTRUCTIONS FOR P/N 63841 BBC ALTERNATOR DRIVE KIT

- This kit is designed to work with Moroso P/N 63840 Alternator mount kit with older style Delco Remy Alternator. Use P/N 23528 Gilmer Drive Pulley if external oil pump is used. Comes complete with all spacers and hardware.
- 2. <u>USE LOCTITE THREAD LOCKING COMPOUND ON</u> BOLT THREADS.

PARTS LIST

- 1. 1/2 20 X 5-3/4 GR8 HHCS
- 2. Stepped Steel Washer
- 3. Aluminum Spacer (.250")
- 4. Alternator Pulley
- 5. Aluminum Spacer (1.06")
- 6. Aluminum Spacer (.905")
- 7. Aluminum Spacer (.500")
- 8. Drive Hub
- 9. 1/8" Sq. Key (Trim to fit)

