



Drive Kit - SBFord
P/N 63846

Parts List

1 Spacer .350"	1 Split Lock Washer	1 Pulley, V-Belt	1 Lock Washer 7/16"
1 Spacer .500"	1 Drive Gear 16T	1 Woodruff Key	1 Stepped Steel Washer
2 Spacer .905"	2 Belt Guides	1 Mandrel	1 HHCS 7/16 x 7.5"
1 Drive Hub	1 SBF, Drive Spacer	4 Socket Head Cap Screw	

This Drive Kit is designed to work with a Moroso Dry Sump Pump and Moroso Vacuum Pump mounted with a Moroso part #63911 Ford Vacuum Pump, Mounting Bracket, #63810 Alt. Mounting Bracket and #64810 Alt. Pulley. The diagram below shows one of the many arrangements of the Drive Kit.

