



INSTALLATION INSTRUCTIONS

P/N 64031

PARTS LIST

- 1 .120" Aluminum Shim
- 1 .050" Aluminum Shim
- 1 .070" Aluminum Shim

INSTALLATION

This crank pulley shim kit has been designed to fit both Small Block and Big Block Chevrolet engines. To use this kit on a Big Block Chevy, cut the tabs off (see below) and grind or file the radius smooth.

