



SPARK PLUG INDEXING WASHERS

14mm FLAT-SEAT PLUGS ONLY!

INCLUDES (10) OF EACH:

THICK ROTATION COLOR

.040 105° COPPER

.050 210° YELLOW

.064 315° CLEAR ZINC

INSTALLATION INSTRUCTIONS

First mark the plug insulator as to electrode location and screw the plug into the desired cylinder and tighten to 10 ft-lbs. Select the proper washer, place it on the plug and tighten to 10 ft-lbs. Check to make sure the electrode is in its desired location

MAY BE REUSED !! IF NOT OVER TIGHTEND !!