



PART # 72195

1. Install brackets as shown.
2. Use bolts included in kit to install brackets.

