



Step 1: Place Velcro loops as shown in (4) places



Step 2: Place Velcro hooks on top of Velcro loops previously installed



Step 3: Place double sided tape on inside of cover centered front to rear and side to side, peel backing as shown



Step 4: Place cover over ABS pump



Step 5: Firmly press front of cover to seat Velcro dots

# MOROSO®



Installation complete