



U – Joint Girdle, 1350 Series Race Yoke P/N  
85830

**INSTALLATION INSTRUCTIONS**  
**Parts List**

- 2 Aluminum Girdles
- 4 3/8 – 24 Counterbore Bolts
- 4 12 – point Flange Nuts

Remove existing u-joint straps.

Push driveshaft towards transmission to gain added clearance for installation of Girdle and Fasteners.

Place 3/8 Bolts through holes in Girdles and secure over u-joint bearing caps with the Flange Nuts.

Tighten bolts evenly making sure that the Girdles come down straight and not cocked to one side. Torque fasteners to 45 ft/lbs.

If needed, grind or file the yoke – **DO NOT GRIND THE GIRDLES!**

85830INST