



WHEEL RIM SCREWS

P/N 90100

INSTALLATION INSTRUCTIONS

PARTS: 35 – Wheel Rim Screws

1. Mark and center punch eight locations evenly spaced around the outer flange of the rim so the screws will penetrate into the tire bead.
2. Drill the holes using a 13/64" drill bit. Leave enough room to the edge of the rim to accommodate a 3/8" socket.
3. Deburr the holes, then mount and inflate tires to 25 psi.
4. Use a 3/8" socket to install the screws through the rim and into the tire bead.
5. Inflate/Deflate tire to normal operating pressure.

NOTE: When installing the screws into the rim just snug them up. Over tightening will result in snapping the head off the screw.