



Step 1: Remove cap and install Velcro hook dots as shown



Step 2: Install Velcro loop dots over Velcro hook dots previously installed



Step 3: Place cover over Brake reservoir



Step 4 Press firmly down on cover to secure Velcro dots to inside of cover



Step 5: Re-install cap, Installation Complete



When it comes to quality performance brake master cylinders, Moroso is the brand you can depend on.