



Step 1: Remove fill cap



Step 2: Place Velcro loops as shown



Step 3: Place Velcro hooks on top of Velcro loops previously installed



Step 4: Place cover over brake reservoir



Step 5: Firmly press down on top of cover to seat Velcro dots-



Step 6: Reinstall fill cap, installation complete