



Step 1: Remove fill cap



Step 2: Place Velcro loops as shown



Step 3: Place Velcro hooks on top of Velcro loops previously installed





Step 4: Place cover over brake reservoir



Step 5: Firmly press down on top of cover to seat Velcro dots





Step 6: Reinstall fill cap



Installation complete

When it comes to quality performance brake master cylinders, Moroso is the brand you can depend on.