






















































































Part Number	Mating Part	Description	Picture	ID Mark	Vehicles	In Euro Kit 200-3120	Standard Adapter Kit 200-3100A	Deluxe Adapter Kit 200-3101A
060-0450		Hose Clamp 7/8" I.D. max	 060-0450		General Application		1	
060-1000	060-1300	1/4" Male Bump Tube	 060-1000		Most Asian Vehicles	1	1	
060-1100	060-1400	5/16" Male Bump Tube	 060-1100		Most Asian Vehicles	1	1	
060-1200	060-1500	3/8" Male Bump Tube	 060-1200		Most Asian Vehicles	1	1	
060-1300	060-1000	1/4" Open End Hose	 060-1300		Most Asian Vehicles	1	1	
060-1400	060-1100	5/16" Open End Hose	 060-1400		Most Asian Vehicles	1	1	
060-1500	060-1200	3/8" Open End Hose	 060-1500		Most Asian Vehicles	1	1	
060-1700	062-0170	5/16" Flare, 7/16"-24 - Domestic Vehicles	 060-1700				1	
060-1800	062-0180	3/8" Flare, 5/8"-20 - Domestic Vehicles	 060-1800				1	
060-2000	060-2005	GM 7/16" Inverted Flare Male			GM			
060-2005	060-2000	GM 7/16" Inverted Flare Female			GM			
060-2010	060-2015	GM 1/2" Inverted Flare Male			GM			
060-2015	060-2010	GM 1/2" Inverted Flare Female			GM			
060-2020		GM 1/2" Hose			GM			
060-2025		VW M12			VW			
060-2030		VW M12 with o-ring			VW	2		
060-2035	060-2040	Jeep 5/8-18 male			Jeep			
060-2040	060-2035	Jeep 5/8-18 female			Jeep			
060-2045	060-2050	SAE J512 45 deg flare 5/8 male						
060-2050	060-2045	SAE J512 45 deg flare 5/8 female						
060-2055	060-2060	Ford SAE J512 45 deg flare female			Ford			
060-2060	060-2055	Ford SAE J512 45 deg flare male			Ford			
060-2065	061-1550 (open end hose)	ADAPTER TRANS BMW 14 MM MALE			BMW	1		
060-2070	060-2075	Adapter Trans BMW - M18 x 1.5 M		70	BMW	1		
060-2075	060-2070	Adapter Trans BMW - M18 x 1.5 F		75	BMW	1		
060-2080		Adapter Trans Saab, Citroen, Lancia - M14 x 1.5 M		80	Saab Citroen Lancia	1		
060-2090		Adapter Trans Fiat - M12 x 1.75 M		90	Fiat	1		

060-2095	060-2105	Adapter Trans Audi - M22 x 1.5 M		95	Audi	1		
060-2105	060-2095	Adapter Trans Audi - M22 x 1.5 F		105	Audi	1		
060-2110	NA	Adapter Trans Opel Corsa		110	Opel Corsa	1		
060-2300		14 mm Female				1		
060-2402	060-2740	14mm x 1.5 Banjo			Euro / Asia Vehicles	2		1
060-2600	060-2300 060-2700	16mm x 1.5 Bubble Flare			European Vehicles	1		1
060-2700		Union - M 14mm X 16mm			European Vehicles	1		
060-2740	060-2402	14mm x 1.5 Banjo Bolt			Euro / Asia Vehicles Use with 060-2402	1		1
060-2741	060-2740	14mm Washer			Euro / Asia Vehicles	2		1
060-2742	060-2740	14mm x 1.5 Cap Nut			Euro / Asia Vehicles	1		1
060-3800	061-0605 061-0005 (optional)	#5 SAE Flare - European Vehicles					1	
060-4200	060-1400	5/16" Male Tube with Locking Quick Connect			Dodge / Ford Vehicles	1		1
060-4300	060-1500	3/8" Male Tube with Locking Quick Connect			Dodge / Ford Vehicles	1		1
061-0008		DODGE DIESEL ALLISON 540			DODGE DIESEL ALLISON 540			
061-0010		DODGE DIESEL ALLISON 634			DODGE DIESEL ALLISON 634			
061-0605	062-0140 060-3800	#5 SAE x #6 SAE Union - European Vehicles					1	
061-1008		FLARE COUPLER # 10 x # 8			ALLISON TRANSMISSIONS			
061-1550	062-2040	1/2" Open End Hose			Chrysler V-10 Diesel Use Volvo XC60 & 70	1		1
062-0100	062-2060 062-0110 (old)	5/16" Male Flare-Deep - Ford Vehicles					1	
062-0120	062-1034 062-0130 (old)	3/8" Male Flare-Deep - Ford Vehicles					1	
062-0140	061-0605	#6 SAE Flare - European Vehicles						
062-0170	060-1700	5/16" Female Flare - x 1/4" MPT			General Application			1
062-0180	060-1800	3/8" Female Flare - x 1/4" MPT			General Application			1
062-1034	062-01200 62-0130 (old)	3/8" Female Flare-Deep - Ford Vehicles					1	
062-2000	062-2005	BMW (Jaguar & Mercedes) 12 mm Male O-Ring Type / Flange Style O-Ring P/N: 080-3602			BMW (Jaguar & Mercedes)	1		
062-2005	062-2000	BMW (Jaguar & Mercedes) 12mm Female Receptacle / Flange Type			BMW (Jaguar & Mercedes)	1		
062-2010	062-2015	10mm Male O-Ring Type / Flange Style O-Ring P/N: 080-3402			BMW (Jaguar & Mercedes)	1		
062-2015	062-2010	10mm Female Receptacle / Flange - Style			BMW (Jaguar & Mercedes)	1		

062-2020		BMW 14mm Male			BMW			
062-2040	061-1550	1/2" Male Tube with Locking Quick Connect			Chrysler V-10 Diesel Use with 061-1550 Volvo XC60 & 70	1		1
062-2060	062-1034 062-0130 (old)	3/8" Male Flare-Deep - Ford Vehicles					1	
062-2061	062-2062	Volvo 850 Application, Volvo V-70 All Wheel Drive Male O-Ring Type / Flange Style			Volvo 850 Application, Volvo V-70 All Wheel Drive O'Ring P/N: 080-3602			
062-2062	062-2061	Volvo 850 Application, Volvo V-70 All Wheel Drive Female receptacle / Flange Style			Volvo 850 Application, Volvo V-70 All Wheel Drive			
062-2063	062-2064	Volvo 'S' Series Application Male O-Ring Type / Push Lock Style			Volvo 'S' Series Application Volvo 'V' & 'XC' O'ring P/N: 080-2326	1		
062-2064	062-2063	Volvo 'S' Series Application Female Receptacle / Push Lock Style			Volvo 'S' Series Application Volvo 'V' & 'XC'	1		
062-2065		Note: The center hole is 1/2" ID x 20 thread pitch. Note: O'Ring is not included with adapter. Please remove o'ring from the old filter and install in the adapter.			ALLISON 1000 or SATURN with SPIN-ON TRANSMISSION FILTER			
062-2066	060-1500 062-2050 (old)	3/8" Male Tube with Locking Quick Connect			GM '95 and newer OPEL Insignia Mercedes Chrysler 300C with Hemi 5.7 Liter Engine 05+			1
062-2068A	062-2069	ALLISON 1000 DURAMAX Female O-Ring Type / Flange Style						
062-2069	062-2068A	ALLISON 1000 DURAMAX Male Receptacle / Flange Type						
062-2070	062-2071	Adapter, Fem 2004 F350 Diesel			2004 F350 Diesel			
062-2071	062-2070	Adapter, Male 2004 F350 Diesel			Male 2004 F350 Diesel			
062-2072		G.M. (CADILLAC CTS)						
062-2073	062-2074	MERCEDES BENZ			Mercedes	1		
062-2074	062-2073	MERCEDES BENZ			Mercedes	1		
062-2080	NA	ADAPTER TRANS PSA HEAT EXCH SMALL		062-2080	Peugeot and Citroën			
062-2085	NA	ADAPTER TRANS CITROEN HT EXCH		85	Citroen XM			
062-2090	NA	ADAPTER TRANS PSA HEAT EXCH LGE		062-2090	Peugeot and Citroën			
062-2095	062-3000	VAG Male Adapter		062-3000				
062-3000	062-2095	VAG Female Adapter		062-2095				
062-4301		Ford retaining clip						
062-4400		Adapter, Ford quick disconnect 1/2"						
062-4401		FORD 3/8" - 'double bump'						1
065-1033		Adapter, Drain hook for oil flush						

080-0592	080-0593	MQD X 1/4" FPT			General Application	1		1
080-0593		Coupler, 1/4" MQD x 1/4" MPT, Zn			General Application			
080-0594	080-0595	MQD X 3/8" FPT			General application		1	
080-0595	080-0594	MQD X 3/8" MPT			General application		1	
200-6101		High pressure adapter assembly			General application			

