


INSTALLATION INSTRUCTIONS for JKOPSP OIL PAN/TRANNY SKID PLATE



1– OIL PAN/TRANNY SKID PLATE 1– DS BRACKET 1– PS BRACKET 3– 1/2"x1-1/2 BOLTS 1– 1/2x1-1/4 BOLT 2– 1/2x1-1/4 CARRIAGE BOLT 6– 1/2" LOCK NUTS 11– 1/2" FLAT WASHER 1- 12mm x1.5x45mm BOLT

HARDWARE KIT:

Please read and understand all instructions before beginning the installation of the Skid Plate.

The **JKOPSP** Oil Pan/Tranny Skid Plate is designed to fit the following Jeep® vehicles: 2007 to Current JK Wranglers equipped with 6-cylinder engines (3.8L) and the OEM Exhaust system.

STEP 1:Remove factory transmission skid plate (IF EQUIPPED).

STEP 2: Position skid plate below crossmember. Install 12mm bolt with washer in center hole (see figure 1).

STEP 3:Center skidplate on oilpan.

STEP 4:Using a 1/2" drill bit, drill a hole through the crossmember and install a 1/2" x1-1/2" bolt and nut with a washer on the top and bottom in both drilled holes. (see figure 2).

STEP 5:Loosen both motor mount bolts and drive bolt towards the rear of the vehicle with a rubber hammer (see figure 3).

STEP 6:Insert a 1/2" x 1.5" bolt with a flat washer into the rear hole of the DS motor mount bracket from the top. (see figure 4)

STEP 7: Install DS skid plate bracket over bolt and motor mount bolt. Slide carriage bolt from the inside of skidplate and through the bottom hole of the bracket. Loosely install flat washers and lock nuts. (see figure 5 &5A)

STEP 8:Slip PS skid plate bracket over motor mount bolt and insert a 1/2" x1.25" bolt from the bottom up. Loosely install a flat washer and lock nut. (see figure 6)

STEP 9:Install Carriage bolt, flat, and lock washer through bottom of bracket. When all bolts are started, tighten all bolts. Verify clearance between top of bolt and motor mount and around exhaust pipes. (see figure 7&7A).



FIGURE 1






FIGURE 3





FIGURE 4



FIGURE 5





FIGURE 6





Verify Clearance between Bolt/ Nut and PS Motor Mount !!!

FIGURE 7



FIGURE 7A



