



*Assembly and Installation Instructions for Spark Plug Wire Divider Brackets
#6018, #6022, #6023*

The wire separators supplied with these brackets are designed to fit only 7mm & 8mm ignition wires. Please note that both divider brackets are the same. When you are finished assembling, you will have a right and left side. Care should be taken during assembly and installation so that the satin or anodized finish will not be marred or scratched.

- 1. Take one divider bracket and assemble the wire separators and adjustable tabs as shown on the diagram. Tighten the separators securely. CAUTION: Do not overtighten. Leave the adjustable mounting tab hardware loose enough to slide the tabs for proper spacing and attachment to the lower valve cover bolts.*
- 2. Take the remaining divider bracket and using the opposite side, assemble as above. When completed, you will now have a right and left side.*
- 3. Attach the mounting tabs to the lower valve cover bolts and tighten.*
- 4. Space the divider bracket either forward or to the rear of the engine as desired and tighten the adjustable mounting tabs to the divider brackets securely.*

We recommend disconnecting and routing one wire at a time to help keep them in the proper firing order. Ignition wires should fit easily into separators. Hold brackets secure while inserting wires to prevent bending.