



# INSTALLATION INSTRUCTIONS

## **Street Fire Ford Coil Pack** **1994-2000 Ford 6-Cylinder, PN 5528** **2001-2004 Ford 6-Cylinder, PN 5529**

### **Parts Included:**

1 - Coil

**WARNING:** During installation, disconnect the battery cables. When disconnecting the battery, always remove the Negative cable first and install it last.

1. Before removing the spark plug wires from the original coil, mark the location by cylinder on the coil.
2. Remove the spark plug wires from the coil.
3. Disconnect the main connector from the coil.
4. Remove the four retainers and remove the coil.
5. Position the new coil on the mount, install the retainers and the connector.
6. Install each spark plug wire, making sure they're in the same position as the original coil.