



# INSTALLATION INSTRUCTIONS

## **Blaster™ Coil-on-Plug**

**Ford Modular SOHC, '99-'04, 16-valve, PN 82428**

**Ford Modular SOHC, '05-'07, 4.6L, PN 82438**

**IMPORTANT:** Read the instructions before attempting the installation.

**Parts Included:**

8 - Coils

**WARNING:** During installation, disconnect the battery cables. When disconnecting the battery, always remove the Negative cable first and install it last.

1. Disconnect the coil connector.
2. Remove the coil retaining bolt and remove the coil.
3. Install the new MSD coil over the spark plug. Make sure the boot slides over the plug and fits in place.
4. Install the retaining bolt and plug in the connector.