



INSTALLATION INSTRUCTIONS

Blaster™ Coil-on-Plug

Ford Modular SOHC, '99-'04, 16-valve, PN 82428

Ford Modular SOHC, '05-'07, 4.6L, PN 82438

IMPORTANT: Read the instructions before attempting the installation.

Parts Included:

8 - Coils

WARNING: During installation, disconnect the battery cables. When disconnecting the battery, always remove the Negative cable first and install it last.

1. Disconnect the coil connector.
2. Remove the coil retaining bolt and remove the coil.
3. Install the new MSD coil over the spark plug. Make sure the boot slides over the plug and fits in place.
4. Install the retaining bolt and plug in the connector.