



## Installation Instructions

### Light Bars and Pre-Runners

Models: F99350LH, F08350LH, F043LH,  
F093LH, D043LH, F99350LB, F08350LB,  
F045LB, F094LB & D045LB

#### Hardware Bag Contents

- 2) 1 1/2" x 5/8 Bolts
- 2) 15/16 Nuts
- 2) 2" Washers

#### Recommended Tools:

15/16 wrench and socket wrench

### F043LH, F045LB, F093LH & F094LB

Step 1. Locate the two plastic inserts in each corner of the bumper opening, remove and discard. This will expose a factory mounting location behind the bumper on both sides.

**NOTE:** The mounting locations will be a round hole through a metal plate on both sides.

Step 2. Match up the light bar brackets to the factory mounting holes through the bumper. Next, start a 1 1/2" x 5/8 bolt, 15/16 nut, and 2" washer and hand tighten. Repeat on other side. This concludes the installation.

### F99350LH, F99350LB, F08350LH, & F08350LB

Step 1. Remove the four 18mm bumper bolts that are located beside the tow hooks. **NOTE:**

Make sure the bumper is secure.

Step 2. Re-align the front bumper back with the factory bolt hole locations. Next, align the pre-runner brackets with the bumper bolt locations and re-install the four 18mm bolts and hand tighten. This concludes the installation.

### D043LH & D045LB

3/4 Ton Only

Step 1. Remove all four 13mm bolts from the factory tow hooks and remove hooks.

Step 2. Align the pre-runner/light bar bracket holes with the tow hook bolt locations. Next, align the tow hook holes with the pre-runner/light bar bracket.

Step 3. Re-install the hooks using the four 13mm tow hook bolts (2 per side) and tighten. This concludes the installation.

Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law.

Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.