



**Installation Instructions**  
Light Bar and Pre-Runner  
07-13 Toyota Tundra  
T074LB & T073LH



**Hardware Kit includes:**

- 4) 3/8" x 1 1/2" Hex Bolts
- 10) 3/8" Flat Washers
- 6) 11/16" Hex Head Nuts
- 2) Mounting Brackets

**Recommended Tools:**

- 11/16 Wrench
- 9/16 Wrench

**NOTE:** The 2010-2013 model Tundra requires trimming of the plastic mesh grill inserts located in the bumper slots prior to installation of the light bar.

Step 1: Locate the two factory bumper mounts and remove all six nuts from the factory studs. Next locate the two "L" shaped N-fab brackets marked driver and passenger side. Starting with the driver side bracket, align the three holes in the bracket to the three factory stud locations. **NOTE:** The angled part of the bracket with the two welded threaded mounts and slotted hole should be above the factory bumper studs.

Step 2: Start all three 11/16" nuts on the factory studs and torque to 15-20 ft/lbs. Repeat for the passenger side bracket.

Step 3: Carefully slide the light bar through the slotted hole in the bumper until the light bar brackets are aligned with the bumper mounted brackets. Next, using the 3/8" x 1 1/2" hex head bolts and 3/8" flat washers, start in each bolt location and hand tighten. **NOTE:** Do not use the slotted hole in the center of the bracket.

Step 4: After final positioning, torque each bolt location to 15-20 ft/lbs.  
This concludes the installation.

Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law. Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.

---