



## Installation Instructions

Light Bar / Pre-Runner

12-14 Toyota Tacoma

Part Numbers:

T124LB/T122LH

### Toyota Light Bar/Pre-Runner Installation Instructions

#### Hardware Kit Contains:

- (8) 5/16" x 1" Bolts
- (8) 5/16" Lock Washers
- (8) 5/16" Nuts
- (2) T12 Inner Brackets

#### Recommended Tools:

- Socket Set
- Torque Wrench
- Wrench Set

Step 1: Locate and remove the 3 nuts from the main bumper support on each side of the vehicle. The bumper support is aluminum in color and is held on with 2 nuts on the outer portion and 1 nut on the inner portion of each bracket and the mounting surface resembles a "C" shape.

Step 2: Place the T12 Inner Brackets onto the studs that remain exposed in Step 1. This step is easily achieved by moving the brackets into place from the opening in front of each wheel. Once the brackets are in place, reuse the nuts removed from Step 1 and tighten them to 20 ft. lbs. Refer to the diagram below for the proper positioning.

Step 3: Position the Light Bar/Pre-Runner between the T12 Inner Brackets. Once positioned, hand-tighten the Light Bar/Pre-Runner using the supplied 5/16" Bolts, Nuts, and Washers.

Step 4: Move the Light Bar/Pre-Runner into its final position. Make sure to look for your desired clearance between the light bar and bumper. Once positioned, tighten to 15 ft. lbs.



Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law. Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.