

INSTALLATION GUIDE

Front Control Arm Rear Bushing

Instructions:

1. Raise vehicle and safely support.
2. Remove front wheels, then proceed to remove the front control arms.
3. Using a Press, press out the vertical mount bushing - check for any burrs or cracks in arm.
4. Carefully press new supplied bushing into place.



Fig. 1
Replacement kit

5. Add a small amount of the supplied grease to the bushing ID and face, then insert the supplied steel tubes.



Fig. 2
Caster Increase.

6. Note images regarding tubes -

For caster increase (offset tubes), position the bolt hole towards centre of vehicle - this relates to both LH & RH sides - refer fig. 2.

7. Re-fit arms to vehicle - a wheel alignment is required after install.

8. Re-check all bolts after initial 100kms travelled.