

Fitting Instructions

Control Arm Bushings

Code: Z5282

Application:

HYUNDAI VELOSTER:

Always refer to current catalogue for complete application listing.

Kit Contents:

2x vertical mount bushings.

Install Guide

- Place vehicle on a hoist and safely raise.
- Remove the front wheels then proceed to unbolt the front control arms.
- Using a suitable press, push the OE bushing out of arm.
- Prior to install, note the new bushing design and voiding - one side of bushing is marginally thicker than the other.
- Prior to pressing in, confirm 'thick' side of bushing is upwards and bushing voiding is as per images below.
- For caster adjustment kit, place offset hole 'inwards' - subsequently pushing arm 'outwards'.
- Proceed to push bushing into position - the outer shell should sit central in eyelet.
- Refit arms to vehicle and carry out wheel alignment.
- Re check after initial 100kms.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.