

Fitting Instructions

Front control arm lower bushes

Code: Z5054A

Application:

- Toyota Prado 120 Series & 05-On Toyota Hilux 4WD

Always refer to current catalogue for complete application listing.

Contents:

- 2 x 67035 Bushes smaller diameter
- 2 x 67036 Bushes larger diameter
- 2 x Small crush tubes
- 2 x Large crush tubes
- 4 x 19.5 Inside diameter washers
- 4 x 14.2 Inside diameter washers
- 1 x Grease sachet

Fitting Instructions:

Please read complete fitting instructions and check kit components prior to fitment.

These instructions are to be used in conjunction with the workshop manual, and it is recommended that all work be carried out by a qualified technician.

1. Raise and support the vehicle on chassis stands.
2. Remove the road wheels from vehicle.
3. Remove the two lower ball joint bolts.
4. Remove the shock absorber lower mounting bolt from the lower control arm.
5. Loosen the two inner lower control arm bolts from the vehicle.
6. While supporting the wheel hub assembly remove the two lower control arm bolts and arm from the vehicle.
7. Remove OE lower control arm bushes from the arm
8. Inspect the arm for damage and burrs, repair or replace as necessary.
8. Using a suitable press and press tools install the supplied bushes into the arm making sure that the larger flange width's face outward from the arm.

Note: Install the bushes so that the voiding is placed horizontally in the arm.

9. Apply liberal amounts of grease supplied to the running surface of the bushes and re-fit the arm into the vehicle, making sure the supplied washers are installed on the faces of the bushes refer fig1.
10. Re-install lower control arm to the vehicle and tension all bolts to manufacturers torque specifications.
11. Re-fit road wheels and settle vehicle on the ground.
12. Carry out wheel alignment as required.

Note: It is recommended to re-tension all bolts in approx 100km's of distance travelled.

Fig 1.

