

Instruction Sheet

Steering Rack Mount

Z5375

Application:

- Toyota Prado 95 series
- Hilux 4 Runner 185 series

Install Guide

- Raise the vehicle evenly and safely support.
- Before removing the steering rack unit, lock the steering wheel in the straight ahead position and consult the manufacturers procedure.
- Once the old bushings have been removed, be sure the eyelets are clean from any dirt or grease (remove any sharp edges).

NOTE: This kit is supplied with 2x 32mm length tubes - confirm the OE bolt diameter (14mm or 17mm) and use the appropriate tube. Discard the other.

- Once all bushings and tubes are installed, re-fit the rack to the vehicle as per manufacturers procedure.
- A wheel alignment is recommended directly after the install.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.