



## Concept7 Convertible Top Tonneau Cover Inserts P/N NAD-LTCI-AR Installation Instructions

1. With the top lowered, push and hold the convertible top power button until the tonneau cover extends to the approximate position shown here. Release the button to hold the tonneau cover in place. This provides access to the factory inserts' fasteners on the bottom of the cover.



2. Use an 8mm wrench or socket to loosen and remove the four fasteners holding each insert in place. They are located at each corner of the insert (see arrows in photo at right).



3. After removing the factory insert, gently lower the Nowicki Autosport insert into the tonneau cover and tighten using the factory 8mm fasteners. Repeat the process for the second insert.

