



---

**👁 Note!**

*Please note that there can be small differences between your product and the images in these instructions.*

---

**👁 Note!**

*Please note that during storage and transport, especially at high ambient temperature, some of the oil and grease used for assembly may leak and stain the packaging. This will not cause damage to the product, wipe off the excessive oil or grease with a cloth.*

---

---

**👁 Note!**

*Before you install this product, check the kit contents. If anything is missing, please contact an Öhlins dealer.*

---

**⚠ Warning!**

*Before you install this product, read the Öhlins Owner's manual. This product is an important part of the vehicle and the vehicle stability.*

---

---

**Cancellation kit, Audi R8 2015-**

***35020-28***

**Mounting Instructions**

# MOUNTING INSTRUCTIONS

## **⚠ Warning!**

*We strongly recommend to let an Öhlins dealer install this product.*

## **⚠ Warning!**

*If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.*

## **Front axle right**

**1**

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

**2**

Fix the canceller with supplied cable ties on the vehicle chassis.



# MOUNTING INSTRUCTIONS

## **⚠ Warning!**

*We strongly recommend to let an Öhlins dealer install this product.*

## **⚠ Warning!**

*If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.*

## **Front axle left**

**1**

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

**2**

Fix the canceller with supplied cable ties on the vehicle chassis.



# MOUNTING INSTRUCTIONS

## Rear axle right

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Mount the canceller with the supplied edge clips on the chassis edge. Fix the cable with cable ties.



# MOUNTING INSTRUCTIONS

## Rear axle left

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Mount the canceller with the supplied edge clips on the chassis edge. Fix the cable with cable ties.

