

INSTALLATION INSTRUCTIONS

MODULAR FRONT BAR – PART #
285736 02-06 BUICK Rendezvous

Parts List (Please check that you have all the parts listed below before you start installing)

Quantity	Brush guard installation hardware
2	Mounting brackets
2	U-Bolts
2	Special Bolts with build in self locking tool
12	M12 Nylon lock nuts (19mm socket nuts)
18	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. Remove the plastic factory lower air dam.
3. Install driver side bracket to the main frame with supplied U-Bolt, washers and nuts.



4. Insert the Special bolt thru the oblong hole on the side of the frame. Secure with the supplied washer and nut.



5. Repeat step 3 and 4 on the passenger side.
6. With the help of another person, align and position the Brush Guard onto the installed brackets and securely tighten down with the supplied M12x40 hex bolts, washers, and nuts.
7. Mark and trim lower air dam and reinstall.
8. Finally, make sure all nuts, bolts and brackets are properly tightened