

INSTALLATION INSTRUCTIONS

ONKI MODULAR **BRUSH GUARD** – PART #
367112 03-05 FORD Ranger 2WD

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
12	M12X40 (19mm hex head bolts)
12	M12 Nylon lock nuts (19mm socket nuts)
24	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

1. Identify left and right bracket to be used (D for driver side / P for passenger side).
2. Underneath front bumper, locate bumper bracket that has 3 predrilled holes.



3. Attach bracket to the bumper bracket and align to the predrilled holes, loosely fasten with the supplied M12 X 40 hex bolts and washers and lock nuts
4. Repeat steps 2 thru 3 on the opposite side.
5. With the help of another person, align and position the Brush Guard to the installed mounting bracket and fasten with the supplied M12 X 40 hex bolts, nuts and washers
6. Secure and tighten all nuts and bolts.