

INSTALLATION INSTRUCTIONS

ONKI MODULAR **BRUSH GUARD** – PART #
367737 02-05 FORD Explorer

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
2	1" X 4" nut plates
10	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
20	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

1. On the lower front bumper, locate and remove plastic covers by unplugging plastic rivets in order to install main mounting brackets



2. Underneath the front bumper, locate the oblong holes underneath the main frame. (one on each side)
3. Insert the supplied nut plate thru the oblong hole (one on each side) and align to the existing holes on the bottom of the main frame.
4. Identify left and right brackets to be used (D for driver side / P for passenger side).
5. Slide the mounting bracket thru the opening hole to the bottom of the main frame, align mounting bracket to the nut plate holes and loosely tighten with supplied M12X40 hex bolts and washers.



6. Repeat steps 1 thru 5 on the opposite side.
7. With the help of another person, align and position the Brush Guard to the installed mounting bracket and fasten with the supplied M12 X 40 hex bolts, nuts and washers
8. Secure and tighten all nuts and bolts.