

INSTALLATION INSTRUCTIONS

ONKI MODULAR **BRUSH GUARD** – PART #
647736 98-04 NISSAN Pathfinder

Parts List (Please check that you have all the parts listed below before you start installing)

Quantity	Description
2	Mounting brackets
4	M12 U-bolts
6	M12X40 (19mm hex head bolts)
14	M12 Nylon lock nuts (19mm socket nuts)
20	½" Washers

Installation of Mounting Frame Brackets & Brush Guard

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. Insert U-bolt as show on pictures. Attach bracket and fasten with the supplied nuts and washers.



3. Repeat procedure on the opposite side.
4. Install brush guard to brackets with supplied nuts and bolts and washers.
5. Adjust and securely tighten all bolts and nuts.