


INSTALLATION INSTRUCTIONS

ONKI MODULAR **BRUSH GUARD** – PART #
869372 00-06 TOYOTA Tundra Regular/Access Cab

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
2	M12 U-bolts
2	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
2	Swing away grille locks

Installation of Mounting Frame Brackets & Brush Guard

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. Remove and discard factory tow brackets (relocate passenger side tow hook if equipped to driver side). Install brackets with factory bolts to the tow brackets locations.



3. Install supplied U-bolt from top of the main frame down thru attached wing bracket holes and fasten with supplied washers and nuts.



4. Repeat procedure on the opposite side.
5. With the help of another person, align Brush Guard and securely tighten all bolts, nuts and swing away grille locks.

