



NERF BOARD

Part #: 328072 VEHICLE BRACKETS CONFIGURATION (03/2009)

USE BRACKET # 1,2,3 FOR:

Chevy/GMC

92-99 Full Size Blazer/Tahoe 2Dr/Yukon 2Dr

91-02 Jimmy 4Dr

91-02 S10 Blazer 4Dr



02-08 Envoy/Trail Blazer

USE BRACKET # 1,2,4 FOR

Land Rover

92-02 Range Rover



06-09 Range Rover Sport

USE BRACKETS # 1,2,5 FOR:

Dodge

97-06 Dakota Club Cab (w/o flares)



Ford

95-01 Explorer 4Dr (w/ body cladding)

97-03 F150 Super Cab 2,3,4 Dr



97-98 F250 Super Cab

Honda/Isuzu

94-04 Passport/Rodeo



Hummer

06-08 H3 SUV

Isuzu

05-08 Ascender 5 Passengers

94-04 Rodeo

Jeep

07-09 Wrangler Unlimited 4Dr

Kia

03-08 Sorento

Lexus

03-09 GX470

98-09 LX470/570

Lincoln

07-08 MKX

Mazda

91-94 Navajo 4Dr (w/ body cladding)

Mercedes

98-05 ML Class

Mark & trim under seal plastic to install bracket #5 vertically. Extend bracket #2 to the main frame mark and drill hole to secure bracket. Repeat procedures for the remaining brackets.



Driver side brackets conf. Shown for ML320 01

Mercury

02-06 Mountaineer (w/ body cladding)

Mitsubishi

03-09 Outlander (w/o cladding)

Nissan

03-09 Murano

08-09 Rogue

Oldsmobile

98-05 Bravada

Pontiac

02-06 Montana Regular Wheelbase

Saturn

07-08 Vue

Toyota

03-08 4 Runner **mount #5 on outside pinch weld.*



08-09 Highlander

98-09 Land Cruiser

95-98 T100 Ext Cab

00-06 Tundra Access Cab (w/o flares)



(Configuration to mount on outside pinch weld)